


GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LGQ8857HQ0, LGQ8857HZ0

(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT3405388	Literature Parts Instructions, Installation	11	688150	Cover, Lint Screen White	27	3403498	Connector, 3-Position (Gas Valve)
	LIT3406080	Use & Care Guide		689310	Almond			
	LIT3977704	Label, Wiring Diagram	12	339229	Hinge, R.H.	28	3397695	Wire, Jumper (Guard On/Off)
2	3401684	Wire, Jumper (Black)		339230	Hinge, L.H.	29	3390646	Screw, 8-18 x 5/16
3	694419	Buzzer, Mini	13	688983	Screw, 8-18 x 5/8	30	357213	Nut, Push-In (2)
4		Cap, End (L.H.)	14	3400859	Screw, Grounding	31	8283129	Harness, Wiring
	3358528	White	15	3395683	Connector (Motor)	32	3977410	Wire, Jumper (Temperature)
	3358529	Almond	16		Top	33	3347243	Connector 6-Circuit
5	717252	Plug, 2-Way Terminal		3396022	White	34	3405156	Switch, Finish Guard
6	3397545	Panel, Rear Console	17	343641	Screw, 10-16 x 1/2	35	8283127	Resistor, Assembly
7	3399640	Switch, Temperature	18		Knob, Control	39	3398095	Relay, Push-To-Start
8		Cap, End (R.H.)		3950759	White	48		Timer Knob Assembly
	3358513	White	19	3394427	Clip-Harness		3406143	White
	3358514	Almond	20	388326	Screw, Console		3406144	Almond
9	693995	Screw, Hex Washer Head	21	3976570	Timer Assembly (60 Hz.)	52	94614	Terminal
10	349639	Handle & Lint Screen Assembly	22	3977407	Control, Electronic	53	8054298	Bracket, Control Panel, Control
			23	3391885	Connector, Edge	54		White
			24	3397269	Connector-Timer		3976770	Almond
			25	3401144	Connector, (PTS Relay)	70	3936144	Connector
			26	3403499	Connector, 2-Position (Gas Valve)			

OPTIONAL PARTS (NOT INCLUDED)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH-UP (1/2oz.)			PAINT, BULK (1 qt.)		
	72017	White		799344	White (Uncut)
	72107	Almond		978883	Almond (Uncut)
PAINT, PRESSURIZED SPRAY (13 oz.)			Following May Be Purchased		
	350930	White	DO-IT-YOURSELF REPAIR MANUALS		
	350956	Almond			
	350938	Primer, Gray		LIT677818	Dryer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LGQ8857HQ0, LGQ8857HZ0

(Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LGQ8857HQ0, LGQ8857HZ0

(Designer White) (Designer Almond)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8 (External Ground)	21		Front Panel Assembly	63	660658	Clamp, Motor
2	343641	Screw, 10-16 x 1/2		3403447	White	64	3401775	Valve, Gas 60 Hz. (Complete)
3	693995	Screw, Hex Head		3403448	Almond	65	686590	Ignitor
4		Plug, Strike Hole	23	685203	Clip, Felt Pad (2)	66	3393909	Lock Screw & Washer (8-32 x 5/8)
	3403630	White	24	690081	Catch, Door Assembly	67	3402844	Burner Assembly, 60 Hz. (See Pages 7 & 8 For Further Burner Breakdown)
	3403631	Almond	25	3405246	Seal, Door	68	341029	Clamp, Pipe
5	3396795	Cover, Block	27	342055	Screw, 8-18 x 1/2	69	694572	Kit, Conversion Type 1, 2 & 3 To Type 4 (LPG)
6	3404162	Clamp, Motor (W/Shield)	28	3405514	Hinge, Door	70	694539	Coil, 60 HZ. Split (3 Terminal) (Pilot Position)
7	3396805	Panel, Rear	33	3403431	Strike, Door	71	694540	Coil, 60 HZ. (2 Terminal) (Main)
10	3406105	Door Switch Assembly	35	3402341	Door, Rear	72	694421	Screw, Bracket Mounting (8-32 x 1/2)
11	697773	Screw, 6-20 x 7/8	36		Door, Front	73	694538	Bracket, Coil
14		Plug, Hinge Hole		3402335	White	74	694424	Leak Limiter
	3404413	White		3402336	Almond	75	694423	Screw, Regulator Adjustment
	3404414	Almond	37		Handle, Door	76	694422	Spring, Regulator
16	3392100	Foot, Dryer		3405184	White	79	239822	Plug, Pipe
	279810	Foot-Optional (Extended Length Package of 2) (Not Included)		3405185	Almond			
18		Cabinet	38	3406129	Seal & Bearing Assembly			
	3399585	White	39		Plug, Front Panel			
	3399586	Almond (Includes Illus. Nos. 5,7,16,48, And 57.)		3394975	White			
19	98234	Clip, Ground (2)		3394976	Almond			
20	690363	Lock, Front Top (2)	45	344020	Cord, Power			
			48	3394083	Clip, Front Panel			
			51	238088	Hinge, Top (2)			
			53	691366	Idler & Pulley Assembly			
			56	660996	Belt, Drive			
			57	348780	Base, Motor			
			58	3400500	Bolt, 5/16-18 x 3/4			
			59	3394341	Pulley, 60 Hz.			
			62	3976707	Motor Assembly 60 Hz.			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LGQ8857HQ0, LGQ8857HZ0

(Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LGQ8857HQ0, LGQ8857HZ0
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	487909	Screw, 8-18 x 1/2
7	3392519	Fuse, Thermal
8	3977358	Drum Hole Plug
9	3977425	Thermostat, Internal-Bias
10	694089	Wheel, Blower (Includes Illus. No. 21)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	3394343	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
21	3394196	Seal, Blower
22	3404232	Bracket, Drum Light
23	3406022	Bracket, Bulkhead
24	693995	Screw, 8-18 x 3/8
28	3394231	Clip, Sensor
29	298877	Washer, Insulated
30	348861	Pad, Sensor
31	348859	Electrode, Inside
32	348860	Electrode, Outside
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403414	Bulkhead
49	338906	Sensor, Radiant
53	3402841	Lens, Drum Light
62	692526	Ring, Bearing
63	97787	Screw, 11-16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal
75	696302	Shield, Exhaust


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3402844 BURNER ASSEMBLY

For Models: LGQ8857HQ0, LGQ8857HZ0

(Designer White) (Designer Almond)

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED, TYPE 3 - MANUFACTURED
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3402844 BURNER ASSEMBLY

For Models: LGQ8857HQ0, LGQ8857HZ0

(Designer White) (Designer Almond)

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED, TYPE 3 - MANUFACTURED
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	3402844	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, 60 Hz.
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	3406052	Elbow Union Assembly
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1, 2 & 3)
to Type (4) L.P.G.

BA-141